

SAFETY SECTION

SCAN FOR
SDS & INFO



TOXICITY 1

FIRE 1

REACTIVITY 0

SPECIAL

WARNING



Skin and eye irritant
Potential respiratory tract irritant
Swallowing will cause gastrointestinal irritation



Do not ingest. If ingested drink large quantities of water. Never give anything by mouth to an unconscious person. Induce vomiting. Get immediate medical attention. If eyes are contacted, flush with water for at least 15 minutes. After initial flushing, remove any contact lenses and continue for at least 15 minutes. See a physician immediately. If you experience an adverse reaction discontinue use. If reaction persists seek medical assistance. Consult the Data Sheet for additional information.
(CAS# 63148-62-9, 9016-45-9, 9036-19-5)



WARNING: This product contains you to chemicals including ethylene oxide which is known to the State of California to cause cancer and/or cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

FEATURES

Mixes easily with water. Use in automatic and hand application. Contains components to help prevent mold in tanks

USE ON

Automatic shaker and manual applications. As a pretreatment for new slings.

SHIPPING/ DOT CLASSIFICATION

LIQUID WAX CLASS 55



SUNRISE
ENVIRONMENTAL SCIENTIFIC
Blending the Demands of Industry and Environment

SLING GLIDE II

SHAKER PAD LUBRICANT

- NON-TOXIC
- NON-FLAMMABLE
- BIODEGRADABLE

LUBRICANTE PARA GOMAS DE EXTRACTOR DE FRUTOS

KEEP OUT OF REACH OF CHILDREN
READ SIDE PANEL BEFORE USING.

SLING GLIDE II

SLING GLIDE II is at the forefront of lubrication technology in the agricultural industry. This compound is designed to lubricate and protect rubber tree shaker slings, while at the same time preventing bark damage to the tree. In automatic water injection systems, SLING GLIDE II will be applied each time the sling is in operation. The surface of the shaker sling will be re-coated with a protective film.

DIRECTIONS:

AUTOMATIC INJECTION SYSTEMS

For most applications, pour 1 quart of SLING GLIDE II into the shaker reservoir and add 25 gallons of water to it. Temperature, humidity and shaking conditions may require altering this dilution. When new shaker slings are installed it is recommended to pre-soak the working surface of the rubber with a 50% solution of SLING GLIDE II and water two or three times prior to installation.

HAND APPLICATION

Dilute SLING GLIDE II with water at a 1:1 ratio. Apply product with hand sprayer or brush once or twice every hour during shaking operation, or as conditions warrant.

SUNRISE ENVIRONMENTAL SCIENTIFIC



800-648-1153 SUNRISENV.COM
PO BOX 10207 - RENO, NEVADA 89510